# KitchenAid<sub>®</sub> **COOKTOP PARTS** 30" ELECTRIC CERAN COOKTOP For Models: KECC506RSS05 (Stainless) Literature Parts

## COOKTOP PARTS For Models: KECC506RSS05

For Models: KECC506RSS05 (Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts Installation Instructions
	8286066	English/French
	8304571	Canadian
	8286073	Wiring Diagram
	W10162162	Use & Care Guide Safer Cooking Tips
	9762761	English
	W10065852	French
2 3 4	8286946	Cooktop, Glass
3	246119	Screw
4	8285935	Bracket, Switch Mounting
5	9759094	Spring Locator (8)
6	3191049	Switch, Infinite LR – RF
	4456027	RR
	8286070	LF
7	3183956	Seal, Switch Shaft
8	8286096BL	Knob, Control (4)
9	8285862	Box, Burner
10	4455917	Bracket, Mounting
11	3400093	Screw
12	3196537	Screw
13	8285469	Seal, Switch
14	311865	Screw
15	9763517	Rail, Element (2)
16	8286344	Rail, Element (1)
17	8286055	Lamp, Hot Surface Indicator
18	W10142240	
19	W 10142240	Frame, Cooktop Element, Surface
19	8523698	1200W LR
	8523697	1500W RF
	8285937	2000/1000W RR
	8285846	2500/1800/900W
		LF
20	4455468	Shield-Heat,
		Control
21		Seal, Heat Shield
	3191839	8.74"
	8286426	6.41"
22	8286607	Grommet, Flexible

## **OPTIONAL PARTS**

For Models: KECC506RSS05 (Stainless)

Illus. Part

No. No. DESCRIPTION

### Miscellaneous

8286642 Tape, Foam

#### **WIRING HARNESS PARTS**

8286417 Harness, Main

3400015 Screw

8286421 Harness, Conduit